

**NZ Applied
Technologies**

150 C New Boston Street
Woburn, MA 01801


Telephone: 617-935-2030
FAX: 617-935-2188
e-mail: 71344.637@compuserve.com

February 1, 1995

Program Officer
Office of Naval Research
800 North Quincy St.
Arlington, VA 22217-5660

Attention: Dr. Richard Brant, ONR Code 312

Dr. Brant,




This is the second bi-monthly progress report under STTR Contract N00014-94-C-0230 entitled, "Novel Growth Method for High Quality GaN Heteroepitaxy".

During this reporting period, NZ Applied Technologies has placed the plasma MOCVD reactor back in service and been growing GaN since early January. We have grown both undoped and Mg-doped GaN. The best results to date are for GaN grown between 650-750°C. These films show relatively broad rocking curve FWHM values of about 0.2 deg. but have strong PL both at room temperature as well as 77 and 10 K. The group at MIT under Prof. L. Kolodziejski provided the PL measurements.

Samples were sent to Prof. Ho's group at Cornell for Raman measurements and to Prof. Schaaf's group for Hall effect measurements. The results of the Raman measurements on Sample 617 [2µm thick] are shown in Fig .1. The Raman peaks are sharp and intense. Sample 617 showed strong luminescence during the measurement.

The highest Hall mobilities measured were 150 cm²/v-sec, for carrier concentrations in the 10¹⁸ cm³ range.

The balance of this report consists of the progress under Prof. Wilson Ho's subcontract at Cornell University.



19951026 104



OFFICE OF THE UNDER SECRETARY OF DEFENSE (ACQUISITION)
DEFENSE TECHNICAL INFORMATION CENTER
CAMERON STATION
ALEXANDRIA, VIRGINIA 22304-6145

IN REPLY
REFER TO

DTIC-OCC

SUBJECT: Distribution Statements on Technical Documents

TO:

OFFICE OF NAVAL RESEARCH
CORPORATE PROGRAMS DIVISION
CNR 353
800 NORTH QUINCY STREET
ARLINGTON, VA 22217-5660

- 1995 1026 104
7201
5661
1. Reference: DoD Directive 5230.24, Distribution Statements on Technical Documents, 18 Mar 87.
 2. The Defense Technical Information Center received the enclosed report (referenced below) which is not marked in accordance with the above reference.
PROGRESS REPORT #2
N00014-94-C-0230
TITLE: NOVEL GROWTH FOR HIGH
QUALITY GaN HETEROEPITAXY
 3. We request the appropriate distribution statement be assigned and the report returned to DTIC within 5 working days.
 4. Approved distribution statements are listed on the reverse of this letter. If you have any questions regarding these statements, call DTIC's Cataloging Branch, (703) 274-6837.

FOR THE ADMINISTRATOR:

1 Encl

GOPALAKRISHNAN NAIR
Chief, Cataloging Branch

DISTRIBUTION STATEMENT A:

APPROVED FOR PUBLIC RELEASE: DISTRIBUTION IS UNLIMITED

DISTRIBUTION STATEMENT B:

DISTRIBUTION AUTHORIZED TO U.S. GOVERNMENT AGENCIES ONLY;
(Indicate Reason and Date Below). OTHER REQUESTS FOR THIS DOCUMENT SHALL BE REFERRED
TO (Indicate Controlling DoD Office Below).

DISTRIBUTION STATEMENT C:

DISTRIBUTION AUTHORIZED TO U.S. GOVERNMENT AGENCIES AND THEIR CONTRACTORS;
(Indicate Reason and Date Below). OTHER REQUESTS FOR THIS DOCUMENT SHALL BE REFERRED
TO (Indicate Controlling DoD Office Below).

DISTRIBUTION STATEMENT D:

DISTRIBUTION AUTHORIZED TO DOD AND U.S. DOD CONTRACTORS ONLY; (Indicate Reason
and Date Below). OTHER REQUESTS SHALL BE REFERRED TO (Indicate Controlling DoD Office Below).

DISTRIBUTION STATEMENT E:

DISTRIBUTION AUTHORIZED TO DOD COMPONENTS ONLY; (Indicate Reason and Date Below).
OTHER REQUESTS SHALL BE REFERRED TO (Indicate Controlling DoD Office Below).

DISTRIBUTION STATEMENT F:

FURTHER DISSEMINATION ONLY AS DIRECTED BY (Indicate Controlling DoD Office and Date
Below) or HIGHER DOD AUTHORITY.

DISTRIBUTION STATEMENT X:

DISTRIBUTION AUTHORIZED TO U.S. GOVERNMENT AGENCIES AND PRIVATE INDIVIDUALS
OR ENTERPRISES ELIGIBLE TO OBTAIN EXPORT-CONTROLLED TECHNICAL DATA IN ACCORDANCE
WITH DOD DIRECTIVE 5230.25, WITHHOLDING OF UNCLASSIFIED TECHNICAL DATA FROM PUBLIC
DISCLOSURE, 6 Nov 1984 (Indicate date of determination). CONTROLLING DOD OFFICE IS (Indicate
Controlling DoD Office).

The cited documents has been reviewed by competent authority and the following distribution statement is
hereby authorized.

A
(Statement)

OFFICE OF NAVAL RESEARCH
CORPORATE PROGRAMS DIVISION
ONR 363
800 NORTH QUINCY STREET
ARLINGTON, VA 22217-5660

(Controlling DoD Office Name)

(Reason)

Debra T. Hughes
(Signature & Typed Name)

DEBRA T. HUGHES
CORPORATE PROGRAMS DIVISION
OFFICE

(Assigning Office)

(Controlling DoD Office Address,
City, State, Zip)

19 SEP 1985

(Date Statement Assigned)

During this past two months, successful growth of single crystal AlN on Si(100) was accomplished. The Si(100) substrate was first sputter cleaned, with Auger showing a surface without any contamination. The 3/4"x3/4" substrate was then introduced into the growth chamber via a load-lock transfer system. Supersonic gas beams of triethylaluminum (TEA) and ammonia (NH₃) were used as the aluminum and nitrogen sources, respectively. The base pressure of the growth chamber was 5×10^{-10} Torr, which increased to 5×10^{-6} Torr during the growth. Single crystal films were grown if these precursors were seeded in helium. The films grown with nitrogen as the seed gas were poor visually and gave no discernible x-ray diffraction peaks. Since the precursors are accelerated to higher energies when seeded in helium compared to nitrogen, these results point out the important role incident translational energy has on the growth of thin films. It is believed that the extra translational energy enhances the two-dimensional diffusion of the growth species on the surface, leading to improved conditions for single crystal growth. The thickness of the AlN films range from 0.5 μm to 1 μm . The AlN films are hexagonal; x-ray diffraction shows the FWHM of the (002) diffraction peak in the θ -2 θ scan to be in the range 0.45 degrees to 0.28 degrees, depending on the growth conditions, as shown in Fig. 2. A thin buffer layer of AlN is grown first at 450 °C, followed by growth at a higher temperature of 600 - 700 °C. Auger spectra taken after the growth show small amount of carbon and oxygen contamination in addition to the expected Al and N peaks. Most of the FWHM is believed to be due to the large lattice mismatch between the Si(100) substrate and the AlN film.

To date, both single crystals of GaN and AlN films have been successfully grown on Si by the use of supersonic gas jets with FWHM in the θ -2 θ scans of about 0.3 degrees. The dependence on the carrier gas was strikingly observed for both films. Further improvements of these films with growth on the SiC substrate and a SiC thin film first grown on Si are planned for the next two months, as well as electrical measurements on these films.


Raman spectra on GaN films growth on sapphire by remote plasma MOCVD at NZ Applied Technologies have been measured with the state-of-the-art micro- and macro-Raman spectrometer at Cornell University. The FWHM in the θ -2 θ scans of these films lies in the range 0.25 - 0.30 degrees. Strong photoluminescence is observed, however, from these films.

The construction of the apparatus for the growth of thin films with slit-nozzles is progressing rapidly. It is expected that towards the end of the

Dist	Avail and/or Special
A-1	

next two months (April), growth of SiC, GaN, and AlN will commence on 4-inch diameter Si wafers. The base pressure of the growth chamber will be in the 10^{-10} Torr range, with the pressure increased to 10^{-2} Torr range during the growth. This pressure range lies in-between our current operating pressures and those used in MOCVD. The ability to grow such large area films is especially attractive to the industry.

Sincerely,

A handwritten signature in black ink, appearing to read "Peter E. Norris". The signature is fluid and cursive, with the first name "Peter" being the most prominent.

Dr. Peter E. Norris
Principal Investigator

APPLICATIONS LAB
D.I.L.O.R.
Version 3.00
EG&G DILOR
XY

OPERATOR: JFT
 DATE : 26-1-1995
 SAMPLE : Gan617
 GRATING : 120M
 TREAT. : /
 REMARK : 1200 macro 300sec -y (zx) y 295K
 EXCITATION (nm) : 514.532
 LASER POW. (mW) : 10
 FOREMONO. (cm-1) : 0800.1
 SPECTRO. (cm-1) : 0800.1
 SLIT WIDTH (fm) : 150
 SPECT. SLIT WIDTH (cm-1) : 5.28
 DETECTOR : 1024
 FILTER :
 INTEGRATION TIME (s) : 0300.00
 NUMBER OF ACCUMULATIONS: 1




FIG. 1




FIG. 2